






Unboxing








































≈5cm

Front View











- 2. Press "Refresh Ports" button, and then select the correct COM-port
- 3. Press OK










NOTE:


This calibration step together with previous calibration of table are very important for the following reasons:


- ✓ Prevents damage to printer
- ✓ Ensures optimal adhesion of object to print bed.



- No air gap
- No contact between nozzle and table


Calibration Successful





NOTE:

Lowering the switching vane means that the print bed will stop further away from the nozzle tip.



Copinters_gadget

Previous Manual Control | Str Card |

Copiect Placement | Slicer | Previous Manual Control | Str Card |

Compared to the structure | Structure |

- ✓ Clean the heated bed with a detergent like blue spirit or alcohol
- ✓ Press indicated temperature buttons
- ✓ Check if temperature is rising.
- If not press this button twice; the printer might be in standby mode due to long inactivity.

33

- 29 ✓ Wait until temperature set points are reached.
 - ✓ Make sure nothing is blocking any axes







32a

If print object didn't adhere correctly to the heated bed, please go to step 23 and 28

Remove object after print completes:

- ✓ Let bed cool down
- ✓ Don't vertically pull object away from print bed.
- ✓ Start peeling at edges
- ✓ After peeling edge, try to twist it from bed.





Congratulations, you've made your first print!

Tip: consult the **user manual** for more detailed information, and join our **user forum** to get the most out of your printer